



# 4WD (w/o 2-4 SELECT SW EXCEPT CALIFORNIA)





# 4WD (w/o 2-4 SELECT SW EXCEPT CALIFORNIA)

## SERVICE HINTS

### A16 ADD CONTROL RELAY

3-6 : Closed with ignition SW at **OFF** position or ignition SW on and detection SW (Transfer 4WD position) at **OFF** position

4-6 : Closed with ignition SW at **ON** position or ignition SW on and detection SW (Transfer 4WD position) at **ON** position

### P1 A/T INDICATOR SW [PARK/NEUTRAL POSITION SW]

4-7 : Closed with A/T shift position at **P** position

### D4 DETECTION SW (TRANSFER NEUTRAL POSITION)

1-2 : Closed with transfer position at **N** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page	
A6	28 (5VZ-FE)	D4	30 (3RZ-FE)	J10	B	31 (3RZ-FE)
	30 (3RZ-FE)		D5	28 (5VZ-FE)	J12	
A16	32	E5		A	33	P1
A22	28 (5VZ-FE)		E6			
	30 (3RZ-FE)	E8		D	33	V7
C10	32		F7			
C13	32	J9		A	29 (5VZ-FE)	31 (3RZ-FE)
D3	28 (5VZ-FE)		J10			
	30 (3RZ-FE)					
D4	28 (5VZ-FE)					

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
3D	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3I		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB2	36 (5VZ-FE)	Engine Wire and Differential Wire (Front Differential Upper Side)
	38 (3RZ-FE)	
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	40	Engine Wire and Cowl Wire (Right Kick Panel)
IK3		

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	36 (5VZ-FE)	Front Left Fender
	38 (3RZ-FE)	
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire	I9	40	Cowl Wire

