

## REMOVAL

### 1. SUPPORT BODY WITH SAFETY STANDS

- (a) Jack up and support the body on safety stands.
- (b) Lower the axle housing until the leaf spring tension is free, and keep it at this position.

### 2. REMOVE REAR SHOCK ABSORBER

- (a) Remove the 2 rear shock absorber set bolts.

**Torque:**

**2WD: 26 N·m (260 kgf·cm, 19 ft·lbf)**

**4WD and pre runner: 71 N·m (730 kgf·cm, 53 ft·lbf)**

- (b) Remove the rear shock absorber.