


DISASSEMBLY

1. **REMOVE FUEL PUMP FROM FUEL PUMP BRACKET**
 - (a) Disconnect the fuel pump connector.
 - (b) Pull off the lower side of the fuel pump from the pump bracket.
 - (c) Disconnect the fuel hose from the fuel pump, and remove the fuel pump.
 - (d) Remove the rubber cushion from the fuel pump.



2. **REMOVE FUEL PUMP FILTER FROM FUEL PUMP**

- (a) Remove the clip.

HINT:

At the time of installation, please refer to the following items.
Install the pump filter with a new clip.

- (b) Pull out the pump filter.