


## REMOVAL

### 1. REMOVE FRONT FENDER WHEEL OPENING MOULDING

- (a) Remove the 3 bolts and mudguard.
- (b) Remove the 6 screws and front fender wheel opening moulding.



### 2. REMOVE QUARTER WHEEL OPENING MOULDING

Remove the 6 screws and quarter wheel opening moulding.