


INSPECTION

1. INSPECT A/C INDICATOR OPERATION

- (a) Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 4.
- (b) Push the A/C button in and then check that the indicator lights up.


If operation is not as specified, replace the switch.



2. INSPECT DIMMING OPERATION

- (a) Connect positive (+) lead from the battery to terminal 6 and negative (-) lead to terminal 4 and 1.
- (b) Connect the positive (+) lead from the battery to terminal 3 and then check that the indicator dims.

If operation is not as specified, replace the switch.



3. INSPECT A/C SWITCH CONTINUITY

| Condition/Circuit | Tester connection | Specified condition |
|----------------------|-------------------|---------------------|
| OFF | – | No continuity |
| ON | 5 – 6 | Continuity |
| Illumination circuit | 3 – 1 | Continuity |

If operation is not as specified, replace the switch or test the bulb.