


REMOVAL

1. DISCONNECT LEVEL WARNING SWITCH CONNECTOR
2. TAKE OUT FLUID WITH SYRINGE

NOTICE:

Do not let brake fluid remain on a painted surface. Wash it off immediately.




3. DISCONNECT BRAKE LINES

Using SST, disconnect the 5 brake lines.

SST 09023-00100

Torque: 15 N·m (155 kgf-cm, 11 ft-lbf)



4. REMOVE MASTER CYLINDER

(a) Remove the 4 nuts, 3-way and check valve bracket.

Torque: 13 N·m (130 kgf-cm, 9 ft-lbf)

(b) Pull out the master cylinder and gasket.