


DISASSEMBLY

1. CHECK COMPANION FLANGE RUNOUT

Using a dial indicator, measure the vertical and lateral runout of the companion flange.

Maximum: runout: 0.09 mm (0.0035 in.)

If the runout exceeds the maximum, replace the companion flange.




2. CHECK RING GEAR RUNOUT

Using a dial indicator, measure the ring gear runout.

Maximum runout: 0.05 mm (0.0020 in.)

If the runout exceeds the maximum, replace the ring gear.



3. CHECK RING GEAR BACKLASH

Using a dial indicator, while holding the companion flange, measure the ring gear backlash.


Backlash: 0.13 – 0.18 mm (0.0051 – 0.0071 in.)

HINT:

Measure at 3 or more positions around the circumference of the ring gear.

If the backlash is not within the specified value, adjust the side bearing preload or as necessary.

4. CHECK TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION (See page SA-169)




5. CHECK SIDE GEAR BACKLASH

Using a dial indicator, measure the side gear backlash with holding one pinion gear toward the case.

Backlash: 0.05 – 0.20 mm (0.0020 – 0.0079 in.)

If the backlash is not within the specified value, replace the side gear thrust washer of the different thickness (See page SA-169).



6. MEASURE DRIVE PINION PRELOAD

Using a torque wrench, measure the preload of the drive pinion using the backlash between the drive pinion and ring gear.

Preload (at starting):

0.6 – 0.9 N·m (7 – 10 kgf·cm, 5.7 – 8.3 in.-lbf)

7. CHECK TOTAL PRELOAD

Using a torque wrench, measure the total preload with the teeth of the drive pinion and ring gear in contact.

Total preload (at starting):


Drive pinion preload plus

0.4 – 0.6 N·m (4 – 6 kgf·cm, 3.5 – 5.2 in.-lbf)


If necessary, disassemble and inspect the differential.

8. REMOVE COMPANION FLANGE


(a) Using a chisel and hammer, unstake the staked part of the nut.



(b) Using SST to hold the flange, remove the nut.
SST 09330-00021




(c) Using SST, remove the companion flange.
SST 09950-30011 (09951-03010, 09953-03010, 09954-03010, 09955-03030, 09956-03050)




9. REMOVE FRONT OIL SEAL


Using SST, remove the oil seal from the differential carrier.
SST 09350-32014 (09308-10010)



10. REMOVE FRONT BEARING AND BEARING SPACER
- (a) Using SST, remove the bearing from the drive pinion.
SST 09556±22010
- If the front bearing is damage or worn, replace the front bearing.
- (b) Remove the 2 washers and bearing spacer.



11. REMOVE DIFFERENTIAL CASE
- (a) Place matchmarks on the bearing cap and differential carrier.
- (b) Remove the 4 bolts and bearing cap.



- (c) Using SST and a plastic hammer, remove the 2 side bearing plate washers.
SST 09504±22011
- HINT:
Measure the plate washer and note down the thickness.
- (d) Remove the differential case with the bearing outer race from the carrier.


HINT:
Tag the bearing outer races to show the location for reassembling.

12. REMOVE DRIVE PINION FROM DIFFERENTIAL CARRIER

Remove the drive pinion with the rear bearing.



13. REMOVE DRIVE PINION REAR BEARING
- Using SST and a press, remove the bearing from the drive pinion.
SST 09950±00020
- HINT:
If the drive pinion or ring gear is damaged, replace them as a set.



14. REMOVE FRONT AND REAR BEARING OUTER RACES AND ADJUSTING WASHER


NOTICE:

Do not remove the outer races except when replacing the bearings.

Using a brass bar and hammer, remove the outer races and adjusting washer from the carrier.

HINT:

Measure the adjusting washer and note down the thickness.





15. REMOVE RING GEAR

- (a) Place matchmarks on the ring gear and differential case.
- (b) Remove the 12 ring gear set bolts.
- (c) Using a plastic hammer, tap on the ring gear to separate it from the differential case.

16. CHECK DIFFERENTIAL CASE RUNOUT

- (a) Install the differential case in the differential carrier (See page SA-169).
- (b) Using a dial indicator, measure the differential case runout.
Maximum case runout: 0.04 mm (0.0016 in.)
- (c) Remove the differential case.




17. REMOVE SIDE BEARINGS

Using SST, remove the 2 side bearings from the differential case.

SST 09950-40011 (09951-04010, 09952-04010, 09953-04020, 09954-04010, 09955-04061, 09957-04010, 09958-04011), 09950-60010 (09951-00480)

HINT:

Fix the claws of SST to the notch in the differential case.



18. DISASSEMBLE DIFFERENTIAL CASE ASSEMBLY

- (a) Using a pin punch and hammer, remove the straight pin.
- (b) Remove the pinion shaft, 2 pinion gears, pinion gear thrust washers, side gears and side gear thrust washers from the differential case.