



REMOVAL

1. DRAIN ENGINE COOLANT
2. REMOVE FRONT BUMPER FILLER
3. REMOVE RADIATOR GRILLE
 - (a) Remove the 4 screws and clearance lights.



- (b) Remove the 1 screw, 11 clips and radiator grille.
4. DISCONNECT UPPER RADIATOR HOSE
5. DISCONNECT RADIATOR RESERVOIR HOSE
6. DISCONNECT LOWER RADIATOR HOSE
7. REMOVE RADIATOR NO.2 FAN SHROUD
8. A/T:
DISCONNECT OIL COOLER HOSES



9. REMOVE RADIATOR

Remove the 4 bolts and the radiator.

Torque: 12 N·m (120 kgf-cm, 8.7 ft-lbf)

HINT:

Insert the tabs of the radiator support through the radiator service holes.