

REMOVAL

1. REMOVE FRONT WHEEL ARCH MOULDING

- (a) Remove the 2 screws and mudguard.
- (b) Remove the 5 screws.
- (c) Using a screwdriver, pry up the wheel arch moulding and remove it.

HINT:

Tape the screwdriver tip before use.

2. REMOVE REAR WHEEL ARCH MOULDING

- (a) Remove the 8 screws.
- (b) Using a screwdriver, pry up the wheel arch moulding and remove it.

HINT:

Tape the screwdriver tip before use.