


## HOOD ADJUSTMENT

BO06Z-02

### HINT:

Since the centering bolt is used as the hood hinge set bolt, the hood cannot be adjusted with it on. Substitute the bolt with the washer for the centering bolt.



### 1. ADJUST HOOD IN FORWARD/ REARWARD AND LEFT/ RIGHT DIRECTIONS

Adjust the hood by loosening the hood side hinge bolts.

#### Torque:


**A: 13 N·m (130 kgf·cm, 10 ft·lbf)**

**B: 18 N·m (180 kgf·cm, 13 ft·lbf)**



### 2. ADJUST FRONT EDGE OF HOOD IN VERTICAL DIRECTION

Adjust the hood by turning the cushions.



### 3. ADJUST HOOD LOCK

Adjust the lock by loosening the bolts.

**Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)**