


INTERIOR LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 46)

- * 1 : REGULAR CAB
- * 2 : EXTRA CAB
- * 3 : EXTRA CAB, REGULAR CAB W/ PERSONAL LIGHT
- * 4 : EXTRA CAB, REGULAR CAB W/O PERSONAL LIGHT



SERVICE HINTS**D15, D16 DOOR COURTESY SW LH, RH**

1-GROUND : Closed with door open

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
D15	32	D24	32	I16	B 34
D16	32	I13	33	J1	33
D18	34	I15	A 33	P5	B 34
D19	34	I16	A 34		A 34

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
1H	22	Roof Wire and J/B No.1 (Lower Finish Panel)
3C	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG1	40	Cowl Wire and Roof Wire (Left Kick Panel)
IH2	40	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IL2	40	Front Door RH Wire and Cowl Wire (Right Kick Panel)

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B2	42	Roof Wire	B3	42	Roof Wire