

TF0516

DISASSEMBLY


- 1. INSPECT DRIVE SPROCKET THRUST CLEARANCE**
Using a feeler gauge, measure the drive sprocket thrust clearance.

Standard clearance:

0.10 – 0.25 mm (0.0039 – 0.0098 in.)

Maximum clearance: 0.25 mm (0.0098 in.)


If the clearance exceeds the maximum, replace the drive sprocket.



TF0517

- 2. M/T:
REMOVE HIGH AND LOW CLUTCH SLEEVE ASSEMBLY**


- Using a snap ring expander, remove the snap ring.
- Remove the clutch sleeve and 3 shifting keys.
- Using a press, remove the clutch hub, 2 key springs and key retainer.



TF0549

- 3. A/T:
REMOVE HIGH AND LOW CLUTCH SLEEVE ASSEMBLY**

- Using a snap ring expander, remove the snap ring.
- Remove the clutch sleeve.
- Using a press, remove the clutch hub.



TF0518


- 4. w/ A.D.D.:
REMOVE BEARING, SPACER AND DRIVE SPROCKET WITH FRONT DRIVE CLUTCH SLEEVE ASSEMBLY**

- Using SST and a press, remove the bearing.
SST 09555-55010

- w/o One touch 2-4 selector system:


Remove these parts.

- Spacer and ball
- Drive sprocket with front drive clutch sleeve assembly
- Needle roller bearing
- Synchronizer ring




TF0620

TRANSFER - REAR OUTPUT SHAFT




- (c) w/ One touch 2-4 selector system:
Remove these parts.
 - Spacer and ball
 - Drive sprocket with front drive clutch sleeve assembly
 - Needle roller bearing
 - Synchronizer outer ring, center ring and inner ring
- (d) Remove the front drive clutch sleeve assembly from the drive sprocket.



5. **w/o A.D.D.:**
REMOVE BEARING, SPACER AND DRIVE SPROCKET WITH FRONT DRIVE CLUTCH SLEEVE

- (a) Using SST and a press, remove the bearing.
SST 09555-55010



- (b) Remove these parts.
 - Spacer and ball
 - Drive sprocket with front drive clutch sleeve
 - Needle roller bearing
 - (c) Remove the front drive clutch sleeve from the drive sprocket.
6. **w/ A.D.D.:**
REMOVE 3 SHIFTING KEYS AND 2 KEY SPRINGS FROM FRONT DRIVE CLUTCH SLEEVE