



G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness
 ▽ : Location of Ground Points


[5VZ-FE]



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
EB2	Engine Wire and Differential Wire (Front Differential Upper Side)
ED1	Sensor Wire and Engine Wire (Over the Cylinder Head)
EE1	Engine Wire and Sensor Wire (Over the Cylinder Head)
EF1	Cowl Wire and Engine Room Main Wire (Right Fender)


G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness
 ▽ : Location of Ground Points


[3RZ-FE, 2RZ-FE]



○ : Location of Splice Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine Room Main Wire and Engine No.2 Wire (Near the Battery)
EB2	Engine Wire and Differential Wire (Front Differential Upper Side)
EF1	Cowl Wire and Engine Room Main Wire (Right Fender)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness
 ▽ : Location of Ground Points



○ : Location of Splice Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IF1	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IF2	
IF3	
IG1	Cowl Wire and Roof Wire (Left Kick Panel)
IH1	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IH2	
II1	Cowl Wire and Floor No.3 Wire (Instrument Panel Brace)
IJ1	Cowl Wire and A/C Sub Wire (Behind the Glove Box)
IK2	Engine Wire and Cowl Wire (Right Kick Panel)
IK3	
IK5	
IL1	Front Door RH Wire and Cowl Wire (Right Kick Panel)
IL2	
IM1	A/C Sub Wire and A/C Wire (Behind the Glove Box)
IP1	Floor No.3 Wire and Floor No.3 Wire (Behind the Radio and Player)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
BN1	Frame Wire and Cowl Wire (Under the Driver's Seat)
BN4	
BO1	Frame Wire and Diff. Lock Wire (Rear Side Member LH)
BO2	