



# COMBINATION METER (w/ TACHOMETER)




- \* 1 : W/ CRUISE CONTROL
- \* 2 : W/O CRUISE CONTROL
- \* 3 : COLUMN A/T
- \* 4 : FLOOR A/T
- \* 5 : 3RZ-FE, 2RZ-FE
- \* 6 : 5VZ-FE
- \* 7 : W/ FUEL LEVEL WARNING
- \* 8 : CALIFORNIA 3RZ-FE AND 2RZ-FE
- \* 9 : EXCEPT \*8

C10 (A), C11 (B), C12 (C), C13 (D)  
COMBINATION METER



# COMBINATION METER (w/ TACHOMETER)





# COMBINATION METER (w/ TACHOMETER)

## SERVICE HINTS

### B2 BRAKE FLUID LEVEL WARNING SW

1-2 : Closed with float down

### C10 (A), C12 (C), C13 (D) COMBINATION METER

(A) 5, (D)1-GROUND : Approx. 12 volts with ignition SW on

(A) 7, (C) 1, (D)12-GROUND : Always continuity

### P4 PARKING BRAKE SW

1-2 : Closed with parking brake lever pulled up

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B2	28 (5VZ-FE)	J9	A	V10	31 (3RZ-FE, 2RZ-FE)
	30 (3RZ-FE, 2RZ-FE)				29 (5VZ-FE)
C10	A 32	J10	B	W1	29 (5VZ-FE)
C11	B 32				31 (3RZ-FE, 2RZ-FE)
C12	C 32	O2		W2	A 29 (5VZ-FE)
C13	D 32				31 (3RZ-FE, 2RZ-FE)
D8	32	P4		B 29 (5VZ-FE)	
F8	34	V10	29 (5VZ-FE)		31 (3RZ-FE, 2RZ-FE)

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
1C		
1D		
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3C		
3D		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	40	Engine Wire and Cowl Wire (Right Kick Panel)
BN1	42	Frame Wire and Cowl Wire (Under the Driver's Seat)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	36 (5VZ-FE)	Front Left Fender
	38 (3RZ-FE, 2RZ-FE)	
EB	36 (5VZ-FE)	Under the Data Link Connector 1
	38 (3RZ-FE, 2RZ-FE)	Near the Throttle Body
EF	38 (3RZ-FE)	Ignition Coil Bracket
ID	40	Left Kick Panel
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement



**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	<a href="#">40</a>	Cowl Wire			