


PRESSURE SWITCH ON-VEHICLE INSPECTION


AC08U-01

1. SET ON MANIFOLD GAUGE SET (See page AC-19)
2. REMOVE GLOVE COMPARTMENT DOOR (See page BO-47)
3. DISCONNECT CONNECTOR FROM COOLING UNIT
4. SET VEHICLE IN THESE CONDITIONS:
 - (a) Running engine at 2,000 rpm
 - (b) Blower speed control switch at HI
 - (c) Temperature control lever MAX. COOL
 - (d) A/C switch ON



5. INSPECT PRESSURE SWITCH OPERATION

- (a) Connect the positive (+) lead from the ohmmeter to terminal 1 and negative (-) lead to terminal 4.



- (b) Check continuity between terminals when refrigerant pressure is changed, as shown in the illustration. If operation is not as specified, replace the pressure switch.