

## DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the diagnostic trouble code check, check the circuit listed for that code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Detection Item	Trouble Area
12 (DI-622)	Actuator Circuit	<ul style="list-style-type: none"> <li>• Connector of cruise control actuator and ECU</li> <li>• STOP fuse and stop light switch</li> <li>• Cruise control actuator and ECU</li> </ul>
14 (DI-625)	Actuator Mechanical Malfunction	<ul style="list-style-type: none"> <li>• Connector of cruise control actuator and ECU</li> <li>• Cruise control actuator and ECU</li> </ul>
21 (DI-626)	Open in Vehicle Speed Sensor Circuit	<ul style="list-style-type: none"> <li>• Harness or connector between vehicle speed sensor and combination meter, combination meter and cruise control actuator and ECU</li> <li>• Speed sensor (in combination meter)</li> <li>• Combination meter</li> <li>• Cruise control actuator and ECU</li> </ul>
23 (DI-628)	Vehicle Speed Signal abnormal	<ul style="list-style-type: none"> <li>• Speed sensor (in combination meter)</li> <li>• Combination meter cable</li> <li>• Cruise control actuator and ECU</li> </ul>
32 (DI-629)	Control Switch Circuit	<ul style="list-style-type: none"> <li>• Harness or connector between control switch and cruise control actuator and ECU</li> <li>• Cruise control switch</li> <li>• Cruise control actuator and ECU</li> </ul>