

DISASSEMBLY

1. REMOVE HEATER RADIATOR

- (a) Remove the 3 screws and 2 plates and clamp.
- (b) Pull out the heater radiator.
- (c) Remove the 2 screws and 2 clips, then disconnect the heater radiator pipes.

HINT:

At the time of reassembly, please refer to the following item.

Do not reuse 2 O-rings.

2. REMOVE AIR VENT DUCT

Remove the 2 screws and duct.