



TAILLIGHT AND ILLUMINATION





TAILLIGHT AND ILLUMINATION

SERVICE HINTS

C14 LIGHT CONTROL SW [COMB. SW]

14-16 : Closed with light control SW at **TAIL** or **HEAD** position

TAIL RELAY [R/B NO.2]

3-5 : Closed with light control SW at **TAIL** or **HEAD** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page		
A14	32	J9	A	29 (5VZ-FE)	R1	A	33
A19	32	J10	B	29 (5VZ-FE)	R2	B	33
C5	32			31 (3RZ-FE,2RZ-FE)		C	33
C13	32	J12		33	R3		33
C14	32	L1		34	R4		33
E4	33	L2		34	R6		34
G3	33	P2		29 (5VZ-FE)	R7		34
H6	33		31 (3RZ-FE,2RZ-FE)	R15		33	
H7	33	P3		29 (5VZ-FE)	S4		33
I15	A		33		31 (3RZ-FE,2RZ-FE)		
J9	A	31 (3RZ-FE,2RZ-FE)	P19	33			

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3C		
3F		
3H	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3I		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
II1	40	Cowl Wire and Floor No.3 Wire (Instrument Panel Brace)
BN1	42	Frame Wire and Cowl Wire (Under the Driver's Seat)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	36 (5VZ-FE)	Front Left Fender
	38 (3RZ-FE, 2RZ-FE)	
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	36 (5VZ-FE)	Engine Room Main Wire	B6	42	Frame Wire
	38 (3RZ-FE, 2RZ-FE)		B7		
I6	40	Cowl Wire	B8		

