


INSPECTION


1. PRETENSIONER IS NOT ACTIVATED

- (a) Perform a diagnostic system check.
(See page [DI-456](#))




- (b) Perform a visual check which includes the following items with the front seat outer belt removed from the vehicle.

- Regular cab:
Check for cuts and cracks in, or marked discoloration on the retractor cover.
- Extra cab:
Check for cuts and cracks in, or marked discoloration on the quarter trim.
- Check for cuts and cracks in wire harness, and for chipping in connectors.



- Check for deformation of the quarter panel.



- Check for cuts miute cracks in wire harness or marked discoloration on the front seat outer belt.


CAUTION:

For removal and installation of the front seat outer belt, see page [BO-98](#) and [BO-110](#).

Be sure to follow the correct procedure.

2. PRETENSIONER IS ACTIVATED

- Perform a diagnostic system check.
(See page [DI-456](#))



- Perform a visual check which includes the following items with the front seat outer belt removed from the vehicle.
 - Check for deformation of the quarter panel.
 - Check for damage on the connector and wire harness.