


REMOVAL

1. REMOVE MASTER CYLINDER (See page [BR-11](#))
2. DISCONNECT VACUUM HOSE FROM BRAKE BOOSTER
3. REMOVE RETURN SPRING
4. REMOVE CLIP AND CLEVIS PIN



5. REMOVE BRAKE BOOSTER
 - (a) Remove the clevis from the push rod.
 - (b) Remove the 4 booster installation nuts.
 - (c) Remove the booster and gasket.