


SENSOR ROTOR (A340E) ON-VEHICLE REPAIR

AT07E-02

1. REMOVE PROPELLER SHAFT (See page [PR-3](#))




2. REMOVE NO.1 AND NO.2 VEHICLE SPEED SENSORS (See page [AT-7](#))

3. JACK UP TRANSMISSION SLIGHTLY

Securely support the transmission on a transmission jack. Lift the transmission slightly from the crossmember.


4. REMOVE CROSSMEMBER

(a) Disconnect the crossmember from the O-ring.



(b) Remove the 4 bolts on the rear mounting side from the engine rear mounting insulator.


(c) Remove the 4 nuts, bolts, washers and crossmember.



5. REMOVE ENGINE REAR MOUNTING INSULATOR AND ENGINE MOUNTING SPACER

(a) Remove the 4 bolts and engine rear mounting insulator from the engine mounting spacer.


(b) Remove the 4 bolts and engine mounting spacer from the transmission.



6. REMOVE EXTENSION HOUSING AND GASKET

Remove the 6 bolts, gasket and extension housing.

If necessary, tap the extension housing with a plastic hammer or a block of wood to loosen it.



Q03902

7. REMOVE SPEEDOMETER DRIVE GEAR AND SENSOR ROTOR

Remove the speedometer drive gear and sensor rotor from the output shaft.

8. INSTALL SPEEDOMETER DRIVE GEAR AND SENSOR ROTOR

Install the speedometer drive gear and sensor rotor to the output shaft.


9. INSTALL EXTENSION HOUSING AND GASKET

- (a) Apply sealant or equivalent to the bolt threads.

Sealant:

Part No. 08833 – 00080, THREE BOND 1344, LOCTITE 242 or equivalent

- (b) Install the extension housing with a new gasket to the case.




D02802

- (c) Install and torque the 6 bolts.

Torque: 36 N·m (370 kgf·cm, 27 ft·lbf)

HINT:

The 2 lower bolts are shorter.



D02801

10. INSTALL ENGINE REAR MOUNTING INSULATOR AND ENGINE MOUNTING SPACER

- (a) Install the 4 bolts and engine mounting spacer to the transmission.

Torque: 28.5 N·m (291 kgf·cm, 21 ft·lbf)

- (b) Install the 4 bolts and engine rear mounting to the engine mounting spacer.

Torque: 65 N·m (660 kgf·cm, 48 ft·lbf)



D02807

11. INSTALL CROSSMEMBER

- (a) Install the 4 nuts, bolts, washers and crossmember.

Torque: 72 N·m (734 kgf·cm, 53 ft·lbf)

- (b) Install the 4 bolts on the rear mounting side to the engine rear mounting insulator.

Torque: 18.5 N·m (189 kgf·cm, 14 ft·lbf)

- (c) Connect the crossmember to the O-ring.

12. INSTALL NO.1 AND NO.2 VEHICLE SPEED SENSORS (See page AT-7)

13. INSTALL PROPELLER SHAFT (See page PR-8)