

## DISASSEMBLY

### NOTICE:

- Do not disassemble the column tube assembly.
- When using a vise, do not overtighten it.

**1. REMOVE COLUMN UPPER BRACKET AND COLUMN UPPER CLAMP (See page [SR-16](#))**

**2. REMOVE TURN SIGNAL BRACKET**

Remove the 3 bolts and turn signal bracket.

**3. REMOVE COLUMN SHIFT LEVER ASSEMBLY**

Remove the 3 bolts and column shift lever assembly.