


## REASSEMBLY

### 1. INSTALL NEW BEARING

- Using SST and a press, install a new bearing to the steering knuckle.  
SST 09527-17011, 09950-60020 (09951-00910)
- Using snap ring pliers, install a snap ring.



### 2. INSTALL NEW OIL SEAL (OUTSIDE)

- Using SST and a plastic hammer, install a new oil seal (outside).  
SST 09223-15030, 09527-17011
- Coat the oil seal lip with MP grease.

### 3. INSTALL AXLE HUB TO STEERING KNUCKLE

- Install the dust cover to the steering knuckle with the 4 bolts.

**Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)**


- Using SST and a press, install the axle hub to the steering knuckle.

SST 09649-17010

### 4. INSTALL ABS SPEED SENSOR ROTOR/SPACER

#### NOTICE:

**Do not scratch the serration of the speed sensor rotor.**




### 5. w/ Free wheel hub (4WD) and Pre runner: INSTALL NEW LOCK NUT

- Using SST, install and torque a new lock nut to the axle hub.

SST 09318-12010

**Torque: 274 N·m (2,800 kgf·cm, 203 ft·lbf)**

- Using a chisel and hammer, stake the lock nut.





### 6. w/o Free wheel hub (4WD only): INSTALL BEARING SPACER

Using SST and a press, install the bearing spacer.

SST 09950-60010 (09951-00650),

09950-70010 (09951-07150)



**7. 4WD:****INSTALL NEW OIL SEAL (INSIDE)**

- (a) Using SST and a plastic hammer, install a new oil seal (inside).

SST 09527-17011

**HINT:**

Strike the SST on its circumference evenly.

- (b) Coat the oil seal lip with MP grease.

**8. Pre runner:****INSTALL GREASE CAP**