


ABS Warning Light Circuit

CIRCUIT DESCRIPTION

If the ECU detects trouble, it lights the ABS warning light while at the same time prohibiting ABS control. At this time, the ECU records a DTC in memory.

After removing the short pin of the DLC1, connect terminals Tc and E₁ of the DLC1 to make the ABS warning light blink and output the DTC.

WIRING DIAGRAM



F00778

INSPECTION PROCEDURE

Troubleshooting in accordance with the chart below for each trouble symptom.

ABS warning light does not light up	Go to step 1
ABS warning light remains on	Go to step 2

1	Check ABS warning light.
----------	---------------------------------

See Combination Meter Troubleshooting on page [BE-2](#).

NG	Repair bulb or combination meter assembly.
-----------	---




Check for open in harness and connector between GAUGE fuse and ABS ECU (See page IN-28).	
---	--

2	Is DTC output?
----------	-----------------------

Check DTC on page [DI-415](#).

YES	Repair circuit indicated by the code output.
------------	---



3	Check for short in harness and connector between GAUGE fuse and ABS ECU (See page IN-28).
----------	--

NG	Repair or replace harness or connector.
-----------	--



Check and repair ABS ECU.
