


## INSTALLATION

### NOTICE:

- Never use seat belt pretensioner from another vehicle. When replacing parts, replace them with new parts.
- Make sure that the front seat outer belt is installed with the specified torque.
- If the front seat outer belt has been dropped, or there are cracks, dents or other defects in the case or connector, replace the front seat outer belt with a new one.
- When installing the front seat outer belt, take care that the wiring does not interfere with other parts and is not pinched between other parts.



### 1. Extra cab:

#### INSTALL FRONT SEAT OUTER BELT


- (a) Install the retractor of front seat outer belt.
- (1) Install the retractor of front seat outer belt with the 2 bolts.

#### Torque:

**Upper bolt: 4.9 N·m (50 kgf·cm, 43 in.-lbf)**


**Lower bolt: 43 N·m (440 kgf·cm, 32 ft-lbf)**

- (2) Connect the pretensioner connector as shown in the illustration.




- (b) Install the quarter trim.
- (c) Install the coat hook with the screw.
- (d) Install the front and rear seat outer belt floor anchors with the 2 bolts.

**Torque: 43 N·m (440 kgf·cm, 32 ft-lbf)**




- (e) Install the lock handle.
- (1) Install the lock handle with the 2 screws.
- (2) Install the cover.
- (f) Install the front and rear seat outer belt shoulder anchors with the 2 bolts, then close the covers.


**Torque: 43 N·m (440 kgf·cm, 32 ft-lbf)**



- (g) Install the rear seat cushions with the 4 bolts.  
**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**
- (h) Install the back panel lower garnish.



- (i) Install the back panel trim with the 3 bolts.  
**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**
- (j) Install the back panel upper garnish.
- (k) Install the door scuff plate with the 4 screws.



## 2. Regular cab:

### INSTALL FRONT SEAT OUTER BELT

- (a) Install the retractor of front seat outer belt.
  - (1) Install the retractor of front seat outer belt with the 2 bolts.  
**Torque:**  
**Upper bolt: 4.9 N·m (50 kgf·cm, 43 in.-lbf)**  
**Lower bolt: 43 N·m (440 kgf·cm, 32 ft·lbf)**
  - (2) Connect the pretensioner connector as shown in the illustration.
- (b) Install the retractor cover with the clip.
- (c) Install the front seat outer belt shoulder anchor with the bolt.  
**Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)**
- (d) Install the front seat outer belt floor anchor with the bolt.  
**Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)**