


AUTOMATIC TRANSMISSION SYSTEM OPERATION

AT018-01



| Shift lever position | Gear position | C ₀ | C ₁ | C ₂ | | B ₀ | B ₁ | B ₂ | B ₃ | | F ₀ | F ₁ | F ₂ |
|----------------------|---------------|----------------|----------------|----------------|------|----------------|----------------|----------------|----------------|------|----------------|----------------|----------------|
| | | | | I.P. | O.P. | | | | I.P. | O.P. | | | |
| P | Parking | ○ | | | | | | | ○ | ○ | ○ | | |
| R | Reverse | ○ | | ○ | ○ | | | | ○ | ○ | ○ | | |
| N | Neutral | ○ | | | | | | | | | ○ | | |
| D | 1st | ○ | ○ | | | | | | | | ○ | | ○ |
| | 2nd | ○ | ○ | | | | | ○ | | | ○ | ○ | |
| | 3rd | ○ | ○ | | ○ | | | ○ | | | ○ | | |
| | O/D | | ○ | | ○ | ○ | | ○ | | | | | |
| 2 | 1st | ○ | ○ | | | | | | | | ○ | | ○ |
| | 2nd | ○ | ○ | | | | ○ | ○ | | | ○ | ○ | |
| L | 1st | ○ | ○ | | | | | | ○ | ○ | ○ | | ○ |

I.P.: Inner Piston
O.P.: Outer Piston

D00790