


REMOVAL

1. REMOVE STEERING WHEEL
(See page [SR-13](#), [SR-25](#) or [SR-33](#))
2. REMOVE STEERING COLUMN COVERS
3. REMOVE COMBINATION SWITCH



4. REMOVE LOWER LH FINISH PANEL
 - (a) Remove the 2 screws and hood lock release lever.
 - (b) Remove the fuse box opening cover.
 - (c) Remove the 4 bolts, screw and lower LH finish panel.
5. w/ Rear console box:
REMOVE REAR CONSOLE BOX
 - (a) Remove the 2 bolts, 2 screws and rear console box.
 - (b) Remove the rear console box cover.
6. REMOVE FRONT CONSOLE BOX (See page [BO-43](#))
7. REMOVE UPPER CONSOLE BOX MOUNTING BRACKET

Remove the 2 screws and upper console box mounting bracket.

8. REMOVE LOWER CENTER COVER

Remove the 2 clips and lower center cover.

9. REMOVE NO.2 HEATER TO REGISTER DUCT


Remove the screw and No.2 heater to register duct.

10. REMOVE CENTER CLUSTER FINISH PANEL

- (a) Remove the heater control knobs.
- (b) Using a screwdriver, remove the heater control panel.

HINT:

Tape the screwdriver tip before use.



- (c) Remove the 2 screws.
- (d) Using a screwdriver, remove the center cluster finish panel.

HINT:


Tape the screwdriver tip before use.

- (e) Disconnect the cutoff switch connectors and other connectors.

NOTICE:

When handling the switch connector, take care not to damage the cutoff wire harness.

- (f) Remove the cigar lighter hole bezel from the center cluster finish panel.
- (g) Remove the front ash receptacle box and retainer from the center cluster finish panel.




11. REMOVE STARTER SWITCH BEZEL

Using a screwdriver, remove the starter switch bezel.

HINT:

Tape the screwdriver tip before use.



12. REMOVE CLUSTER FINISH PANEL

(a) Remove the 3 screws.

(b) Using a screwdriver, remove the cluster finish panel.

HINT:

Tape the screwdriver tip before use.

13. REMOVE RADIO AND STEREO OPENING COVER

14. REMOVE COMBINATION METER

15. REMOVE NO.1 REGISTER


Remove the 2 screws and No.1 register.

16. REMOVE NO.1 HEATER TO REGISTER DUCT

Remove the screw and No.1 heater to register duct.

17. REMOVE STEERING COLUMN

(See page [SR-13](#), [SR-25](#) or [SR-33](#))




18. REMOVE GLOVE COMPARTMENT DOOR

Remove the 2 screws and glove compartment door.

19. REMOVE GLOVE COMPARTMENT DOOR REINFORCEMENT

Remove the 3 screws and glove compartment door reinforcement.

20. REMOVE NO.4 HEATER TO REGISTER DUCT

**21. DISCONNECT AIRBAG CONNECTOR**

(a) Remove the No.1 under cover.


NOTICE:

When handling the airbag connector, take care not to damage the airbag wire harness.

(b) Pull up and disconnect the airbag connector.

22. REMOVE LOWER NO.2 FINISH PANEL

Remove the 3 screws and lower No.2 finish panel.

23. REMOVE HEATER CONTROL INSTALLATION SCREWS**24. REMOVE LOWER CENTER FINISH PANEL****25. REMOVE INSTRUMENT PANEL**

Remove the 2 bolts, 2 nuts and instrument panel.

Torque:

Bolt: 20 N·m (205 kgf·cm, 15 ft·lbf)

26. REMOVE NO.1 BRACE

Remove the 3 bolts and No.1 brace.

27. REMOVE NO.2 BRACE

Remove the 2 bolts and No.2 brace.

28. REMOVE CENTER HEATER TO REGISTER DUCT

Remove the screw and center heater to register duct.

29. REMOVE DEFROSTER NOZZLE**30. REMOVE REINFORCEMENT**

Remove the 3 bolts, 4 nuts and reinforcement.

31. REMOVE SIDE BRACKET

Remove the bolt and side bracket.