




## DISASSEMBLY


### 1. REMOVE VALVE BRACKET

- (a) Remove the nut, bolt and 2 plate washers.
- (b) 2WD:  
Remove the 2 nuts and flexible hose bracket, and remove the valve bracket and set plate from the valve body.
- (c) 4WD and Pre runner:  
Remove the 2 nuts, and remove the valve bracket and set plate from the valve body.




### 2. DISCONNECT SPRING FROM VALVE

Using pliers, remove the clip, and remove the spring from the valve.



### 3. REMOVE SHACKLES NO.1 AND NO.2

- (a) Remove the nut and bolt, and remove the load sensing spring and 2 plate washers.
- (b) Loosen the 2 nuts, and remove the shackle No. 1 from the shackle No. 2.



### 4. DISASSEMBLE LOAD SENSING SPRING

- (a) Remove the 4 bushings, 2 collars and 2 rubber plats.
- (b) Remove the load sensing valve boot and load sensing spring boot.