


STOP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 46)

* 1 : 5VZ-FE
* 2 : 3RZ-FE, 2RZ-FE



SERVICE HINTS**S5 (A), (B) STOP LIGHT SW**

(A) 2-(A) 1, (B) 2-(B) 1 : Closed with brake pedal depressed

 : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
H8	34	R7	34	S5	B 33
R6	34	S5	A	33	

 : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
3C	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IG1	40	Cowl Wire and Roof Wire (Left Kick Panel)
BN1	42	Frame Wire and Cowl Wire (Under the Driver's Seat)

 : GROUND POINTS

Code	See Page	Ground Points Location
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire	B7	42	Frame Wire
B6	42	Frame Wire			