


## REMOVAL

1. REMOVE TIMING BELT (See page [EM-13](#))
2. REMOVE WATER INLET AND THERMOSTAT
3. DISCONNECT NO.2 OIL COOLER HOSE FROM WATER PUMP



### 4. REMOVE WATER PUMP

- (a) Remove the 7 bolts.
- (b) Pry out the water pump.