


## INSPECTION

### 1. INSPECT BACK-UP LIGHT SWITCH CONTINUITY

Condition	Tester connection	Specified condition
Free	–	No continuity
Push	1 – 2	Continuity

If continuity is not as specified, replace the switch.



### 2. INSPECT BACK-UP LIGHT RELAY CONTINUITY

Condition	Tester connection	Specified condition
Constant	1 – 2	Continuity
Apply B+ between terminals 1 and 2.	3 – 5	Continuity

If continuity is not as specified, replace the relay.

### 3. INSPECT PARK/NEUTRAL POSITION SWITCH CONTINUITY

(A43D: See page [AT-2](#))

(A340E, A340F: See page [DI-389](#))