


ENGINE INSPECTION

MA00B-03

HINT:

Inspect these items when the engine is cold.

1. **5VZ-FE ENGINE:**
REPLACE TIMING BELT (See page EM-17)
2. **INSPECT DRIVE BELTS**
(2RZ-FE, 3RZ-FE: See page EM-40)
(5VZ-FE: See page EM-13)
3. **REPLACE SPARK PLUGS**
(2RZ-FE, 3RZ-FE: See page IG-1)
(5VZ-FE: See page IG-1)



4. INSPECT AIR FILTER

- (a) Visually check that the air cleaner element is not excessively dirty, damaged or oily.

HINT:

Oiliness may indicate a stuck PCV valve.

If necessary, replace the air cleaner element.

- (b) Clean the element with compressed air.
First blow from back side thoroughly, then blow off the front side of the element.

5. REPLACE AIR FILTER

Replace the used air cleaner element with a new one.

6. **REPLACE ENGINE OIL AND OIL FILTER**
(2RZ-FE, 3RZ-FE: See page LU-2)
(5VZ-FE: See page LU-2)
7. **REPLACE ENGINE COOLANT**
(2RZ-FE, 3RZ-FE: See page CO-2)
(5VZ-FE: See page CO-2)
8. **INSPECT CHARCOAL CANISTER**
(2RZ-FE, 3RZ-FE: See page EC-8)
(5VZ-FE: See page EC-5)
9. **REPLACE GASKET IN FUEL TANK CAP**
(2RZ-FE, 3RZ-FE: See page SF-24)
(5VZ-FE: See page SF-25)
10. **INSPECT FUEL LINES AND CONNECTIONS**
(2RZ-FE, 3RZ-FE: See page SF-24)
(5VZ-FE: See page SF-25)
11. **INSPECT EXHAUST PIPES AND MOUNTINGS**
(2RZ-FE, 3RZ-FE: See page EM-117)
(5VZ-FE: See page EM-107)

12. REPLACE A/F SENSOR (California Spec.)
(2RZ-FE, 3RZ-FE: See page [SF-50](#))
(5VZ-FE: See page [SF-52](#))
13. REPLACE HEATED OXYGEN SENSOR
(2RZ-FE, 3RZ-FE: See page [SF-54](#))
(5VZ-FE: See page [SF-54](#))