


REPLACEMENT

1. REMOVE AIR CLEANER HOSE
2. DISCONNECT HIGH-TENSION CORDS FROM IGNITION COILS



3. **REMOVE IGNITION COILS**
 - (a) Disconnect the connector from the ignition coil.
 - (b) Remove the bolt and ignition coil from the LH cylinder head.
4. **REINSTALL NEW IGNITION COILS**
 - (a) Connect a new ignition coil to the spark plug, and attach the ignition coil to the cylinder head cover.
 - (b) Install the ignition coil with the bolt.
Torque: 7.8 N·m (80 kgf·cm, 69 in.-lbf)
5. **RECONNECT HIGH-TENSION CORDS TO IGNITION COILS**
6. **REINSTALL AIR CLEANER HOSE**