


BLOWER RESISTOR REMOVAL

AC08N-01

1. REMOVE GLOVE COMPARTMENT DOOR
(See page [BO-47](#))



2. REMOVE BLOWER RESISTOR
 - (a) Disconnect the connector.
 - (b) Remove the 2 screws and blower resistor.