

<b>DTC</b>	<b>41</b>	<b>IG Power Source Circuit</b>
------------	-----------	--------------------------------

### CIRCUIT DESCRIPTION


This is the power source for the ECU, hence the actuators.

DTC No.	DTC Detecting Condition	Trouble Area
41	Vehicle speed is 3 km/h (1.9 mph) or more and voltage of ECU terminal IG1 remains at more than 17 V or below 9.5 V for more than 10 sec.	<ul style="list-style-type: none"> <li>• Battery</li> <li>• IC regulator</li> <li>• Open or short in power source circuit</li> <li>• ECU</li> </ul>

Fail safe function:

If trouble occurs in the power source circuit, the ECU cuts off current to the ABS control (solenoid) relay and prohibits ABS control.

### WIRING DIAGRAM



F00775

### INSPECTION PROCEDURE

<b>1</b>	<b>Check battery positive voltage.</b>
----------	--


**OK:**

**Voltage: 10 – 14 V**

<b>NG</b>	<b>Check and repair the charging system.</b>
-----------	--

<b>OK</b>
-----------

<b>2</b>	<b>Check voltage between terminals IG1 and GND of ABS ECU connector.</b>
----------	--



**PREPARATION:**

Disconnect ABS actuator connector.

**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG1 and GND of ABS actuator harness side connector.


**OK:**

**Voltage: 10 – 14 V**

<b>NG</b>	<b>Go to step 4.</b>
-----------	----------------------

<b>OK</b>
-----------

<b>3</b>	<b>Check continuity between terminals GND of ABS ECU connector and body ground.</b>
----------	---



**CHECK:**


Measure resistance between terminals GND of ABS actuator harness side connector and body ground.

**OK:**

**Resistance: 1 Ω or less**

<b>NG</b>	<b>Repair or replace harness or connector.</b>
-----------	--

<b>OK</b>
-----------

**4 Check ECU-IG fuse.****PREPARATION:**

Remove ECU-IG fuse from J/B No.1.

**CHECK:**

Check continuity of ECU-IG fuse.

**OK:**

**Continuity**

**NG**

**Check for short in all the harness and components connected to ECU-IG fuse (See attached wiring diagram).**

**OK****Check and replace the ABS ECU.**