


TF0512

REPLACEMENT

1. REMOVE FRONT BEARING

Using a press, remove the front bearing.




TF0513

2. REMOVE REAR BEARING

Using SST and a press, remove the rear bearing.


SST 09555-55010



TF0514

3. INSTALL REAR BEARING

Using a press, install a new rear bearing.



Q07210

4. INSTALL FRONT BEARING

Using a press, install a new front bearing.