


Diagnosis Circuit

CIRCUIT DESCRIPTION


This circuit sends a signal to the ECU that DTC output is required.

WIRING DIAGRAM



INSPECTION PROCEDURE

- 1 Check voltage between terminals Tc and E₁ of DLC1.

**CHECK:**

- (a) Turn the ignition switch ON.
 (b) Measure voltage between terminals Tc and E₁ of DLC1.

OK:

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-621](#)).

NG

- 2 Check harness and connector between cruise control actuator and ECU and DLC1, DLC1 and body ground (See page [IN-28](#)).

NG

Repair or replace harness or connector.

OK

Check and replace cruise control actuator and ECU (See page [IN-28](#)).