


# LIGHT REMINDER



## SYSTEM OUTLINE

With the ignition SW in ACC position, current flows to TERMINAL 8 of the integration relay. When the ignition SW is turned to ON position, current flows to TERMINAL 6 of the relay. When the light control SW is turned to TAIL or HEAD position, current is applied to TERMINAL 4 of the relay through the TAIL fuse.

### LIGHT REMINDER SYSTEM

When the light control SW is in TAIL or HEAD position and the driver's door is opened (Door courtesy SW on), as a result, the relay is activated and current flows from TERMINAL 4 of the relay to TERMINAL (A) 5 to TERMINAL 1 of the door courtesy SW LH to GROUND, sounding the light reminder buzzer.

## SERVICE HINTS

### I15 (A) INTEGRATION RELAY

4-GROUND : Approx. 12 volts with light control SW at TAIL or HEAD position

(A) 5-GROUND : Continuity with LH door open

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
D15	32	I15	A	33	

### ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3F	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)