


INSTALLATION

Installation is in the reverse order of removal
(See page AC-88).

HINT:

After installation, adjust the heater control cables.


- (a) Set heater control assembly in these conditions:
- (1) Set heater control assembly at "FRESH" position.
 - (2) Mode control dial at "FACE" position
 - (3) Temperature control dial at "COOL" position



- (b) Adjust air inlet control cable.
Pull the mode control link at "FRESH" position, connect the control cable and lock the clamp.

HINT:


Lock the clamp during lightly pushing the outer cable in the direction, as shown in the illustration.



- (c) Adjust mode control cable.
Pull the mode control link at "FACE" position, connect the control cable and lock the clamp.

HINT:


Lock the clamp during lightly pushing the outer cable in the direction, as shown in the illustration.



- (d) Adjust air mix control cable.
Pull the air mix link at "COOL" position, connect the control cable and lock the clamp.

HINT:

Lock the clamp during lightly pushing the outer cable in the direction, as shown in the illustration.



- (e) Adjust water valve control cable.
Pull the water valve control lever at "COOL" position, connect the control cable and lock the clamp.

HINT:

Lock the clamp during lightly pushing the outer cable in the direction, as shown in the illustration.