


## PARKING LOCK PAWL ON-VEHICLE REPAIR


AT01G-01

1. REMOVE DRAIN PLUG AND DRAIN ATF
2. REMOVE VALVE BODY  
(See page [AT-23](#))



### 3. REMOVE PARKING LOCK PAWL BRACKET

Remove the 2 bolts, wave washers and parking lock pawl bracket.




### 4. REMOVE PARKING LOCK PAWL

- (a) Remove the spring from parking lock pawl pivot pin.
- (b) Remove the pivot pin and parking lock pawl.
- (c) Remove the E-ring from the pivot pin.

### 5. INSTALL PARKING LOCK PAWL

- (a) Install the E-ring to the pivot pin.
- (b) Install the parking lock pawl, pivot pin and spring.




### 6. INSTALL PARKING LOCK PAWL BRACKET

Install the bracket and tighten the 2 bolts with the wave washers.

**Torque: 7.4 N·m (75 kgf·cm, 65 in.-lbf)**

HINT:

Push the parking lock rod fully forward.



### 7. CHECK PARKING LOCK PAWL OPERATION

Shift the manual valve lever to the P position, and check the planetary ring gear is correctly locked up by the lock pawl.

### 8. INSTALL VALVE BODY

(See page [AT-23](#))

### 9. INSTALL DRAIN PLUG

**Torque: 20 N·m (205 kgf·cm, 15 ft·lbf)**

### 10. FILL ATF AND CHECK FLUID LEVEL

(See page [AT-2](#))