


REMOVAL

1. REMOVE EVAPORATOR
(See page [AC-54](#))



2. REMOVE THERMISTOR

- (a) Disconnect the connector clamp.
- (b) Pull out the thermistor from evaporator.