

PROBLEM SYMPTOMS TABLE

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
<ul style="list-style-type: none"> • With the ignition switch at ACC or ON, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed. • SRS warning light is always lit up even when ignition switch is in the LOCK position. 	<ul style="list-style-type: none"> • SRS warning light circuit (Always lights up when ignition switch is in LOCK position.) 	DI-546
<ul style="list-style-type: none"> • With the ignition switch at ACC or ON, the SRS warning light does not light up. 	<ul style="list-style-type: none"> • SRS warning light circuit (Does not light up when ignition switch is turned to ACC or ON.) 	DI-548
<ul style="list-style-type: none"> • DTC is not displayed. • SRS warning light is always lit up in a DTC check procedure. • DTC is displayed without Tc and E1 terminal connection. 	<ul style="list-style-type: none"> • Tc terminal circuit 	DI-552