




VEHICLE LIFT AND SUPPORT LOCATIONS

2WD Except PRE RUNNER:





4WD:



JACK POSITION • • • • • 
Front • • • • • Center of crossmember
Rear • • • • • Under the rear differential

SUPPORT POSITION
Safety stand • • • • • 

PRE RUNNER:**JACK POSITION**

Front Center of crossmember

Rear Under the rear differential

SUPPORT POSITION

B04189