

## **DISASSEMBLY**

### **REMOVE BLOWER MOTOR**

Remove the 3 screws and blower motor.