

REASSEMBLY

1. w/ A.D.D.:


INSTALL NEW BEARINGS

Using SST and a press, install 2 new bearings.

SST 09950-60010 (09951-00380)

Bearing press in depth:

0.3 ± 0.3 mm (0.012 ± 0.012 in.)



2. ASSEMBLE DIFFERENTIAL CASE

(a) Install the 2 thrust washers on the side gears.

HINT:

Refer to the table below to select thrust washers which will ensure that the backlash is within the specification.


Washer thickness:

Thickness mm (in.)	Thickness mm (in.)
0.96 - 1.04 (0.0378 - 0.0409)	1.16 - 1.24 (0.0457 - 0.0488)
1.06 - 1.14 (0.0417 - 0.0449)	1.26 - 1.34 (0.0496 - 0.0528)

(b) Install the 2 side gears, pinion gears, pinion gear thrust washers and pinion shaft in the differential case.

HINT:


Align the holes of the differential case and pinion shaft.



(c) Using a dial indicator, measure the side gear backlash while holding one pinion gear toward the differential case.

Backlash: 0 - 0.20 mm (0 - 0.0079 in.)

If the backlash is not within the specified value, replace the side gear thrust washer of the different thickness.



3. INSTALL STRAIGHT PIN AND STAKE DIFFERENTIAL CASE


(a) Using a pin punch and hammer, install the straight pin through the differential case and hole of the pinion shaft.

(b) Stake the differential case.

4. INSTALL RING GEAR ON DIFFERENTIAL CASE

(a) Clean the contact surfaces of the differential case and ring gear.

(b) Heat the ring gear to about 100°C (212°F) in boiling water.




- (c) Carefully take the ring gear out of the boiling water.
- (d) After the moisture on the ring gear has completely evaporated, quickly install the ring gear to the differential case.

HINT:

Align the matchmarks on the ring gear and differential case.

- (e) Temporarily install 5 new lock plates and 10 bolts so that the bolt holes in the ring gear and differential case are not misaligned.
- (f) After the ring gear has cooled sufficiently, torque the ring gear set bolts.


Torque: 97 N·m (985 kgf-cm, 71 ft-lbf)



- (g) Using a chisel and hammer, stake the 5 lock plates.

HINT:

Stake the claws of the lock plates to fix the bolts. For the claw contacting the protruding portion of the bolt, stake only the half of it along the tightening direction.

**5. INSTALL SIDE BEARINGS**


Using SST and a press, install the bearing into the differential case.


SST 09226-10010

6. INSTALL SIDE BEARING OUTER RACES**HINT:**


When replacing the side bearings, fit the thinnest washers to each bearing and when reusing the bearings, fit the washers with the same thickness as removed.

- (a) Install a new plate washer to the bearing retainer.
- (b) Using SST and a press, install the bearing outer race.
SST 09950-60020 (09951-00790),
09950-70010 (09951-07150)
- (c) Install a new plate washer to the differential carrier.





- (d) Using SST and a press, install the bearing outer race.
 SST 09950-60020 (09951-00790),
 09950-70010 (09951-07150)



7. INSTALL DRIVE PINION FRONT AND REAR BEARING OUTER RACES

Using SST, install the 2 outer races.


SST 09570-22011

8. INSTALL DRIVE PINION FRONT BEARING

- (a) Install the washer on the drive pinion.

HINT:

First fit a washer with the same thickness as the washer which was removed, then after checking the tooth contact pattern, replace the washer with one of a different thickness if necessary.



- (b) Using SST and a press, install the front bearing onto the drive pinion.


SST 09506-30012

9. TEMPORARILY ADJUST DRIVE PINION PRELOAD


- (a) Install the drive pinion, rear bearing and oil slinger.

HINT:

Assemble the spacer and oil seal after adjusting the ring gear tooth contact pattern.



- (b) Using SST, install the companion flange.
 SST 09950-30011 (09951-03010, 09953-03010,
 09954-03010, 09955-03030, 09956-03020)
- (c) Coat the threads of the nut with hypoid gear oil.



(d) Using SST to hold the flange, tighten the nut.


HINT:

Adjust the drive pinion preload by tightening the companion flange nut.

SST 09330-00021

NOTICE:

As there is no spacer, tighten the nut a little at a time, being careful not to overtighten it.



(e) Using a torque wrench, measure the preload of the drive pinion using the backlash between the drive pinion and ring gear.

Preload (at starting):

New bearing

1.2 – 1.9 N·m (12 – 19 kgf·cm, 10.4 – 16.5 in.-lbf)

Reused bearing


0.6 – 1.0 N·m (6 – 10 kgf·cm, 5.2 – 8.7 in.-lbf)

10. INSTALL DIFFERENTIAL CASE IN DIFFERENTIAL CARRIER

11. ADJUST RING GEAR BACKLASH

(a) Install the side bearing retainer with the 10 bolts.

Torque: 69 N·m (700 kgf·cm, 51 ft·lbf)



(b) Using SST and a dial indicator, measure the ring gear backlash.

SST 09564-32011

Backlash: 0.13 – 0.18 mm (0.0051 – 0.0071 in.)

(c) If the backlash is not within the specified value, adjust by either increasing or decreasing the thickness of washers on both sides by an equal amount.

HINT:

There should be no clearance between the plate washer and case. Ensure that there is ring gear backlash.

Washer thickness:

Thickness mm (in.)	Thickness mm (in.)	Thickness mm (in.)
2.00 – 2.02 (0.0787 – 0.0795)	2.27 – 2.29 (0.0894 – 0.0902)	2.54 – 2.56 (0.1000 – 0.1008)
2.03 – 2.05 (0.0799 – 0.0807)	2.30 – 2.32 (0.0906 – 0.0913)	2.57 – 2.59 (0.1012 – 0.1020)
2.06 – 2.08 (0.0811 – 0.0819)	2.33 – 2.35 (0.0917 – 0.0925)	2.60 – 2.62 (0.1024 – 0.1031)
2.09 – 2.11 (0.0823 – 0.0831)	2.36 – 2.38 (0.0929 – 0.0937)	2.63 – 2.65 (0.1035 – 0.1043)
2.12 – 2.14 (0.0835 – 0.0843)	2.39 – 2.41 (0.0941 – 0.0949)	2.66 – 2.68 (0.1047 – 0.1055)
2.15 – 2.17 (0.0846 – 0.0854)	2.42 – 2.44 (0.0953 – 0.0961)	2.69 – 2.71 (0.1059 – 0.1067)
2.18 – 2.20 (0.0858 – 0.0866)	2.45 – 2.47 (0.0965 – 0.0972)	2.72 – 2.74 (0.1071 – 0.1079)
2.21 – 2.23 (0.0870 – 0.0878)	2.48 – 2.50 (0.0976 – 0.0984)	2.75 – 2.77 (0.1083 – 0.1091)
2.24 – 2.26 (0.0882 – 0.0890)	2.51 – 2.53 (0.0988 – 0.0996)	2.78 – 2.80 (0.1094 – 0.1102)

12. MEASURE TOTAL PRELOAD


Using a torque wrench, measure the preload with the teeth of the drive pinion and ring gear in contact.

Total preload (at starting):**Drive pinion preload plus**



0.4 – 0.6 N·m (4 – 6 kgf·cm, 3.5 – 5.2 in.-lbf)

13. INSPECT TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION

- (a) Remove the side bearing retainer and differential case.



- (b) Coat 3 or 4 teeth at three different positions on the ring gear with red lead primer.
- (c) Install the differential case and side bearing retainer.
Torque: 69 N·m (700 kgf·cm, 51 ft·lbf)
- (d) Hold the companion flange firmly and rotate the ring gear in both directions.
- (e) Remove the side bearing retainer and differential case.
- (f) Inspect the tooth contact pattern.



If the teeth are not contacting properly, use the following table to select a proper washer for correction.

Washer thickness:


Thickness mm (in.)	Thickness mm (in.)	Thickness mm (in.)
1.69 - 1.71 (0.0665 - 0.0673)	1.93 - 1.95 (0.0760 - 0.0768)	2.17 - 2.19 (0.0854 - 0.0862)
1.72 - 1.74 (0.0677 - 0.0685)	1.96 - 1.98 (0.0772 - 0.0780)	2.20 - 2.22 (0.0866 - 0.0874)
1.75 - 1.77 (0.0689 - 0.0697)	1.99 - 2.01 (0.0783 - 0.0791)	2.23 - 2.25 (0.0878 - 0.0886)
1.78 - 1.80 (0.0701 - 0.0709)	2.02 - 2.04 (0.0795 - 0.0803)	2.26 - 2.28 (0.0890 - 0.0898)
1.81 - 1.83 (0.0713 - 0.0720)	2.05 - 2.07 (0.0807 - 0.0815)	2.29 - 2.31 (0.0902 - 0.0909)
1.84 - 1.86 (0.0724 - 0.0732)	2.08 - 2.10 (0.0819 - 0.0827)	2.32 - 2.34 (0.0913 - 0.0921)
1.87 - 1.89 (0.0736 - 0.0744)	2.11 - 2.13 (0.0831 - 0.0839)	-
1.90 - 1.92 (0.0748 - 0.0756)	2.14 - 2.16 (0.0843 - 0.0850)	-

14. REMOVE COMPANION FLANGE AND OIL SLINGER (See page SA-52)

15. REMOVE REAR BEARING (See page SA-52)

16. INSTALL NEW BEARING SPACER, REAR BEARING AND OIL SLINGER


(a) Install a new bearing spacer and place the rear bearing and oil slinger.



- (b) Using SST and the companion flange, install the rear bearing, then remove the companion flange.
SST 09950-30011 (09951-03010, 09953-03010, 09954-03010, 09955-03030, 09956-03020)

17. INSTALL OIL SEAL

- (a) Coat a new oil seal lip with MP grease.




- (b) Using SST and a hammer, install the oil seal.
SST 09554-22010

Oil seal drive in depth: 4.5 mm (0.177 in.)


18. INSTALL COMPANION FLANGE

- (a) Place the companion flange on the drive pinion.
(b) Coat the threads of a new nut with hypoid gear oil.



- (c) Using SST to hold the flange, torque the nut.
SST 09330-00021

Torque: 108 N·m (1,100 kgf·cm, 80 ft·lbf)



19. ADJUST DRIVE PINION PRELOAD

Using a torque wrench, measure the preload of the drive pinion using the backlash between the drive pinion and the ring gear.

Preload (at starting):

New bearing

1.2 – 1.9 N·m (12 – 19 kgf·cm, 10.4 – 16.5 in.-lbf)

Reused bearing

0.6 – 1.0 N·m (6 – 10 kgf·cm, 5.2 – 8.7 in.-lbf)

If the preload is greater than the specified value, replace the bearing spacer.

If the preload is less than the specified value, retighten the nut 13 N·m (130 kgf·cm, 9 ft·lbf) a little at a time until the specified preload is reached.


Torque: 223 N·m (2,275 kgf·cm, 165 ft·lbf) or less

If the maximum torque is exceeded while retightening the nut, replace the bearing spacer and repeat the preload adjusting procedure. Do not loosen the nut to reduce the preload.

20. INSTALL DIFFERENTIAL CASE

21. INSTALL SIDE BEARING RETAINER

- (a) Remove any old FIPG material and be careful not to drop oil on the contact surfaces of the differential carrier and side bearing retainer.
- (b) Clean contacting surfaces of any residual FIPG material using gasoline or alcohol.



- (c) Apply FIPG to the side bearing retainer, as shown.

FIPG:

Part No. 08826-00090, THREE BOND 1281 or equivalent

HINT:


Install the side bearing retainer within 10 minutes after applying FIPG.

- (d) Install the side bearing retainer with the 10 bolts.

Torque: 69 N·m (700 kgf·cm, 51 ft·lbf)

22. CHECK TOTAL PRELOAD (See step 12.)**23. RECHECK RING GEAR BACKLASH**

(See page [SA-52](#))

24. RECHECK TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION (See step 13.)**25. CHECK COMPANION FLANGE RUNOUT (See page [SA-52](#))****26. STAKE DRIVE PINION NUT****27. INSTALL SIDE OIL SEAL**


- (a) Using SST and a plastic hammer, install a new oil seal until its surface is flush with the differential carrier end.

SST 09608-32010

- (b) Coat the oil seal lip with MP grease.

28. w/ A.D.D.:**INSTALL INTERMEDIATE SHAFT NO. 1**


- (a) Install a new snap ring to the shaft.



- (b) Using a plastic hammer, install the shaft to the differential case.

- (c) Check that there is 2 – 3 mm (0.08 – 0.12 in.) of play in the axial direction.

- (d) Check that the intermediate shaft will not come out by trying to pull it completely out by hand.



29. w/ A.D.D.:
INSTALL CLUTCH CASE TO DIFFERENTIAL TUBE


- (a) Install a new O-ring to the tube.
- (b) Coat the O-ring with MP grease.
- (c) Install the clutch case to the tube.
- (d) Using a torx socket (E14), torque the 2 torx bolts.

Torque: 78 N·m (800 kgf·cm, 58 ft·lbf)

30. w/ A.D.D.:
INSTALL CLUTCH SLEEVE

31. INSTALL DIFFERENTIAL TUBE TO DIFFERENTIAL

- (a) Remove any old FIPG material and be careful not to drop oil on the contact surfaces of the differential and clutch case.
- (b) Clean surfaces with FIPG material attached to using gasoline or alcohol.



- (c) Apply FIPG to the differential, as shown.


FIPG:

Part No. 08826-00090, THREE BOND 1281 or equivalent

HINT:

Install the differential tube within 10 minutes after applying FIPG.

- (d) Install the differential tube to the differential.
- (e) Clean the threads of the 4 bolts (w/o A.D.D.) or 2 torx bolts (w/ A.D.D.) and retainer bolt holes with toluene or trichloroethylene.



- (f) Apply adhesive to 2 or 3 threads of the bolts end.

Adhesive:

Part No. 08833-00070, THREE BOND 1324 or equivalent

- (g) Torque the 4 bolts (w/o A.D.D.) or 4 torx bolts (w/ A.D.D.). Torx socket E14 (Part No. 09044-00010 or locally manufactured tool).


Torque:

w/o A.D.D.: 105 N·m (1,070 kgf·cm, 77 ft·lbf)

w/ A.D.D.: 78 N·m (800 kgf·cm, 58 ft·lbf)

32. w/ A.D.D.:**INSTALL A.D.D. ACTUATOR**

- (a) Remove any old FIPG material and be careful not to drop oil on the contact surfaces of the actuator and clutch case.
- (b) Clean contacting surfaces of any residual FIPG material using gasoline or alcohol.



- (c) Apply FIPG to the clutch case, as shown.

FIPG:

Part No. 08826-00090, THREE BOND 1281 or equivalent

HINT:

Install the actuator within 10 minutes after applying FIPG.

- (d) Install the A.D.D. actuator with the 4 bolts.

Torque: 21 N·m (210 kgf-cm, 15 ft-lbf)