



INSPECTION

1. INSPECT HEATER RESISTANCE OF HEATED OXYGEN SENSOR

- Disconnect the sensor connector.
- Using an ohmmeter, measure the resistance between terminals +B and HT.

Resistance:

at 20°C (68°F)	11 – 16 Ω
at 800°C (1,472°F)	23 – 32 Ω

If the resistance is not as specified, replace the sensor.

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

- Reconnect the oxygen sensor connector.
- ### 2. Bank 1 Sensor 1: INSPECT OPERATION OF HEATED OXYGEN SENSOR (See page [DI-234](#))
- ### 3. Bank 1 Sensor 2: INSPECT OPERATION OF HEATED OXYGEN SENSOR (See page [DI-243](#))