

REASSEMBLY

NOTICE:

When using a vise, do not overtighten it.

1. INSTALL COLUMN SHIFT LEVER ASSEMBLY

Install the column shift lever assembly with the 3 bolts.

Torque: 9.3 N·m (95 kgf·cm, 83 in.-lbf)

2. INSTALL TURN SIGNAL BRACKET

Install the turn signal bracket with the 3 bolts.

Torque: 3.4 N·m (35 kgf·cm, 31 in.-lbf)

3. INSTALL COLUMN UPPER BRACKET AND COLUMN UPPER CLAMP (See page [SR-19](#))