


TERMINALS OF ECU



H01357

No.	Symbol	Terminal Name
A	-	Electrical Connector Check Mechanism
B	-	Electrical Connector Check Mechanism
C20 - 6	PR+	Squib (Seat belt pretensioner, RH)
C20 - 7	PR-	Squib (Seat belt pretensioner, RH)
C21 - 3	LA	SRS Warning Light
C21 - 5	IG2	Power Source (IGN Fuse)
C21 - 6	ACC	Power Source (CIG Fuse)
C21 - 9	SR+	Front Airbag Sensor (RH)
C21 - 10	P+	Squib (Passenger)
C21 - 11	P-	Squib (Passenger)
C21 - 12	SIL	Diagnosis
C21 - 13	D-	Squib (Passenger)
C21 - 14	D+	Squib (Driver)
C21 - 15	SL+	Front Airbag Sensor (LH)
C21 - 19	Tc	Squib (Driver)
C21 - 20	SR-	Front Airbag Ssensor (RH)
C21 - 26	SL-	Front Airbag Sensor (LH)
C21 - 27	E1	Ground
C21 - 28	E2	Ground
C22 - 1	PL-	Squib (Seat belt pretensioner, LH)
C22 - 2	PL+	Squib (Seat belt pretensioner, LH)