



REMOVAL

1. **DRAIN ENGINE COOLANT**
2. **DISCONNECT LOWER RADIATOR HOSE**
3. **REMOVE THERMOSTAT**
 - (a) Remove the 3 nuts, water inlet and thermostat with gasket from the water pump.
 - (b) Remove the gasket from the thermostat.