

REMOVAL

1. DRAIN ENGINE COOLANT


2. DISCONNECT CABLES:

- (a) w/ Cruise Control:
Disconnect the cruise control actuator cable.
- (b) Disconnect the accelerator cable.
- (c) A/T:
Disconnect the throttle cable.


3. REMOVE AIR CLEANER HOSE

4. REMOVE THROTTLE BODY

- (a) Disconnect the throttle position sensor connector.
- (b) Disconnect the IAC valve connector.
- (c) Disconnect the vacuum hose for the throttle opener.
- (d) Disconnect the water bypass hose (from water bypass pipe).
- (e) Disconnect the water hose (from intake manifold).
- (f) Disconnect the air assist hose.




B06498



S02121

- (g) Remove the 2 bolts, 2 nuts, throttle body and gasket.

Torque: 18 N·m (180 kgf·cm, 13 ft·lbf)



P21153

HINT:

At the time of installation, please refer to the following items. Place a new gasket on the air intake chamber facing the protrusion upward.